



Veloped Rain Cover (S) – User Guide



Rain cover that protects the seat and basket of the Veloped.

Veloped 2-color design: silver/black


Scan the QR-code with your smart phone or device to view video instructions.



① Fasten the string.

Fasten the elastic string around the upper frame tube.

Note: Turn the cover so you get the desired colour on the cover.



② Second attachment point.

The rain cover can also be fastened at the rear end.



③ Front attachment point.

The rain cover is wrapped around the front of the frame.



④ When walking.

Loosen the rear elastic strings when you're walking.



⑤ Store rain cover.

Store the rain cover the basket or in the zippered pocket.



⑥ Ready for use in rainy weather.